

5 Series, i5, & M5			X5 & X5M		
Series / Chassis	Part name	Part number	Series / Chassis	Part name	Part number
5' & M5 / G30 F90	Aluminum		X5 & X5M / G05 F95	Aluminum	
	Front left wheelhouse	41 00 7446651		Frame rail, engine support left	41 00 7417571
	Wheelhousing with VIN, front right	41 00 2456303		Frame rail, engine support right	41 00 7417572
	Wheelhousing without VIN, front right	41 00 7446652		Strut tower, front left	41 00 7933485
	Engine support right	41 00 7359396		Strut tower, front right	41 00 7933486
	Engine support, left	41 00 7359395		Wheel housing strut, front left	41 00 7933479
	Spring support left	41 00 7329873		Wheel housing strut, front right	41 00 7933480
	Spring support right	41 00 7329874		Wheel house, supporting strut exterior left	41 00 7933507
	Support structure for cargo area floor	41 00 7431413		Wheel house, supporting strut exterior right	41 00 7933508
	Side member, inner left	41 00 7431375		Wheel house, supporting strut exterior right	41 00 2464639
	Side member, inner right	41 00 7431376		Steel	
	Rear left wheelhouse, inner half	41 00 7431591		Rear left engine support	41 00 7933493
	Rear right wheelhouse, inner half	41 00 7431592		Rear right engine support	41 00 7933494
5' , M5 & i5 / G60 G90	Aluminum			Reinforcement engine mount rear left	41 00 7933267
	Wheel well left front	41 14 9635093		Reinforcement engine mount right rear	41 00 7933268
	Wheel well right front	41 14 9635094		Left interior column A	41 00 7933501
	Engine support right	41 00 7359396		Right interior column A	41 00 7933502
	Engine support, left	41 00 7359395		Left engine compartment partition	41 00 7933513
	Spring support left	41 00 7329873		Right engine compartment partition	41 00 7933514
	Spring support right	41 00 7329874		Connection engine mount outer left	41 00 7933253
	Rear left side member (ICE/PHEV)	41 11 9635213		Connection engine support outer right	41 00 7933254
	Right rear side member (ICE/PHEV)	41 11 9635214		Crash reinforcement, left	41 00 7933249
	Rear left side member (BEV)	41 11 9635215		Crash reinforcement, right	41 00 7933250
	Right rear side member (BEV)	41 11 9635216		Side frame, exterior, left	41 00 7954993
	Wheel well rear inner left	41 14 9635243		Side frame, exterior, right	41 00 7954994
	Wheel well rear inner right	41 14 9635244		Column a with left rocker panel	41 00 7955059
	Steel			Column B with right rocker panel	41 00 7955060
	Carrier support wheel well left front	41 14 9635095		Side frame, center left	41 00 7955043
	Carrier support wheel well right front	41 14 9635096		Side frame, center right	41 00 7955044
	Rear left engine support	41 11 9635097		Reinforcement door sill left	41 00 7955051
	Rear right engine support	41 11 9635098		Reinforcement door sill right	41 00 7955052
	Rear left engine support (BEV / PHEV)	41 11 9635099		Reinforcement B-pillar left	41 00 7955029
	Rear right engine support (BEV / PHEV)	41 11 9635100		Reinforcement B-pillar right	41 00 7955030
	Wheel housing strut, front left	41 00 7446669		Reinforcement column C, bottom, left	41 00 9481379
	Wheel housing strut, front right	41 00 7446670		Reinforcement column C, bottom, right	41 00 9481380
	Wheel-house inner panel, rear left	41 00 7412963		Reinforcement D-pillar inside left	41 00 7955037
	Wheel-house inner panel, rear right	41 00 7412964		Reinforcement D-pillar inside right	41 00 7955038
	A-column, inner front left	41 14 9635101		Extension, supporting strut left	41 00 9481401
	A-column, inner front right	41 14 9635102		Extension, supporting strut right	41 00 9481402
	Left interior column A	41 14 5A642D3		Left interior side frame	41 00 7955017
	Right interior column A	41 14 5A642D4		Right interior side frame	41 00 7955018
	Side frame outer left	41 30 9627217		Reinforcement column B inside left	41 00 9481365
	Side frame outer right	41 30 9627218		Reinforcement column B inside right	41 00 9481366
	Column A exterior right	41 21 9635524		Support column B left	41 00 9481363
	Left exterior column A	41 21 9635523		Support column B right	41 00 9481364
	Side frame center left	41 21 9627219		Wheelhouse rear, outer half left	41 00 9481375
	Side frame center right	41 21 9627220		Wheelhousing, rear, outer section, right	41 00 9481376
	Support, carrier support, left	41 21 9635495		Left interior column A	41 00 7933261
	Support, carrier support, right	41 21 9635496		Right interior column A	41 00 7933262
	Bulkhead side member left front	41 21 9635499		Rear left side member	41 00 7947381
	Bulkhead side member right front	41 21 9635500		Right rear side member	41 00 7947382
	Reinforcement door sill left	41 21 9635509		Left interior column C	41 00 7947365
	Reinforcement door sill right	41 21 9635510		Right interior column C	41 00 7947366
	Reinforcement C-pillar left	41 21 9635501		Rear left wheelhouse, inner half	41 00 7947371
	Reinforcement C-pillar right	41 21 9635502		Rear right wheelhouse, inner half	41 00 7947372
	Reinforcement, interior roof frame, left	41 21 9635511		Wheelhouse rear, outer half left	41 00 9481375
	Reinforcement, interior roof frame, right	41 21 9635512		Wheelhousing, rear, outer section, right	41 00 9481376
	Side frame inner left	41 20 9627221		Side member, rear lower left	41 00 7947335
	Side frame inner right	41 20 9627222		Side member, rear lower right	41 00 7947336
	Side member inner left (ICE)	41 11 8852445		Left shock absorber support	41 00 7947143
	Side member inner right (ICE)	41 11 8852446		Right shock absorber support	41 00 7947144
	Wheel-house inner panel, rear left	41 20 9635481		Tail cowling outer	41 00 7947332
	Wheel-house inner panel, rear right	41 20 9635478		Interior tail trim	41 00 8498016
	Column B inside right	41 20 9635488			
	Holder B-pillar	41 20 9635491			
	Interior left column B	41 20 9635487			
	Holder B-pillar	41 20 9635491			
	A-pillar inner, rear left	41 20 9635485			
	A-pillar inner, rear right	41 20 9635486			
	End plate side member rear left	41 11 9635229			
	End plate side member rear right	41 11 9635230			
	Covering plate left	41 14 5A65813			
	Covering plate right	41 14 5A65814			
	Extension side member lower right (ICE)	41 11 9635160			
	Extension, side member, lower left (ICE)	41 11 9635159			
	Mount, bumper left	41 00 9631871			
	Mount, bumper right	41 00 9631872			
	Extension, side member, upper left	41 00 7431633			
	Extension, side member, upper right	41 00 7431634			
	Extension, side member, side, left	41 00 7431645			
	Extension, side member, side, right	41 00 7431646			
	Complete tail trim	41 34 9635248			
	Rear trim panel outer skin	41 34 5A65883			

X6 & X6M			X7		
Series / Chassis	Part name	Part number	Series / Chassis	Part name	Part number
X6 & X6M / G06 F96	Aluminum		X7 / G07	Aluminum	
	Frame rail, engine support left	41 00 7417571		Frame rail, engine support left	41 00 7417571
	Frame rail, engine support right	41 00 7417572		Frame rail, engine support right	41 00 7417572
	Strut tower, front left	41 00 7933485		Strut tower, front left	41 00 7933485
	Strut tower, front right	41 00 7933486		Strut tower, front right	41 00 7933486
	Wheel housing strut, front left	41 00 7933479		Wheel housing strut, front left	41 00 7933479
	Wheel housing strut, front right	41 00 7933480		Wheel housing strut, front right	41 00 7933480
	Wheel house, supporting strut exterior	41 00 7933507		Wheel house, supporting strut exterior l	41 00 7933507
	Wheel house, supporting strut exterior	41 00 7933508		Wheel house, supporting strut exterior r	41 00 7933508
	Wheel house, supporting strut exterior	41 00 2464639		Wheel house, supporting strut exterior w	41 00 2464639
	Steel			Steel	
	Rear left engine support	41 00 7933493		Rear left engine support	41 00 7933493
	Rear right engine support	41 00 7933494		Rear right engine support	41 00 7933494
	Reinforcement engine mount rear left	41 00 7933267		Reinforcement engine support rear left	41 00 7933267
	Reinforcement engine mount right rear	41 00 7933268		Reinforcement engine support rear right	41 00 7933268
	Left interior column A	41 00 7933501		Left interior column A	41 00 7933501
	Right interior column A	41 00 7933502		Right interior column A	41 00 7933502
	Left engine compartment partition	41 00 7933513		Left engine compartment partition	41 00 7933513
	Right engine compartment partition	41 00 7933514		Right engine compartment partition	41 00 7933514
	Connection engine mount outer left	41 00 7933253		Connection engine support outer left	41 00 7933253
	Connection engine support outer right	41 00 7933254		Connection engine support outer right	41 00 7933254
	Crash reinforcement, left	41 00 7933249		Crash reinforcement, left	41 00 7933249
	Crash reinforcement, right	41 00 7933250		Crash reinforcement, right	41 00 7933250
	Side frame, exterior, left	41 00 7954997		Side frame, exterior, left	41 00 7955001
	Side frame, exterior, right	41 00 7954998		Side frame, exterior, right	41 00 7955002
	Column a with left rocker panel	41 00 7955081		Column a with left rocker panel	41 00 7955085
	Column B with right rocker panel	41 00 7955082		Column a with right rocker panel	41 00 7955086
	Side frame, middle left	41 00 7954967		Side frame, middle left	41 00 7954971
	Side frame, middle right	41 00 7954968		Side frame, middle right	41 00 7954972
	Reinforcement side sill left	41 00 7955051		Reinforcement side sill left	41 00 7955047
	Reinforcement side sill right	41 00 7955052		Reinforcement side sill right	41 00 7955048
	Reinforcement B-pillar left	41 00 7955031		Reinforcement B-pillar left	41 00 7955033
	Reinforcement B-pillar right	41 00 7955032		Reinforcement B-pillar right	41 00 7955034
	Reinforcement column C, bottom, left	41 00 9498783		Reinforcement column C, bottom, left	41 00 9481381
	Reinforcement column C, bottom, right	41 00 9498784		Reinforcement column C, bottom, right	41 00 9481382
	reinforcement D-pillar inside left	41 00 7955065		reinforcement D-pillar inside left	41 00 7955061
	reinforcement D-pillar inside right	41 00 7955066		reinforcement D-pillar inside right	41 00 7955062
	Extension, supporting strut left	41 00 9481401		Extension, supporting strut left	41 00 9481401
	Extension, supporting strut right	41 00 9481402		Extension, supporting strut right	41 00 9481402
	Left interior side frame	41 00 7955021		Left interior side frame	41 00 7955025
	Right interior side frame	41 00 7955022		Right interior side frame	41 00 7955026
	Reinforcement column B inside left	41 00 9498777		Reinforcement column B inside left	41 00 9481365
	Reinforcement column B inside right	41 00 9498778		Reinforcement column B inside right	41 00 9481366
	Support column B left	41 00 9498775		Support column B left	41 00 9481363
	Support column B right	41 00 9498776		Support column B right	41 00 9481364
	Wheelhouse rear, outer half left	41 00 9498779		Wheelhouse rear, outer half left	41 00 9481377
	Wheelhousing, rear, outer section, riç	41 00 9498780		Wheelhousing, rear, outer section, right	41 00 9481378
	Rear left side member	41 00 7947381		Left interior column A	41 00 7933261
	Right rear side member	41 00 7947382		Right interior column A	41 00 7933262
	Left interior column C	41 00 7947367		Rear left side member	41 00 7947383
	Right interior column C	41 00 7947368		Right rear side member	41 00 7947384
	Rear left wheelhouse, inner half	41 00 7947375		Left interior column C	41 00 7947369
	Rear right wheelhouse, inner half	41 00 7947376		Right interior column C	41 00 7947370
	Wheelhouse rear, outer half left	41 00 9498779		Rear left wheelhouse, inner half	41 00 7947377
	Wheelhousing, rear, outer section, riç	41 00 9498780		Rear right wheelhouse, inner half	41 00 7947378
	Frame side member, rear bottom left	41 00 7947335		Wheelhouse rear, outer half left	41 00 9481377
	Frame side member, rear bottom right	41 00 7947336		Wheelhousing, rear, outer section, right	41 00 9481378
	Side member rear top left	41 00 7947145		Closing plate, longitudinal member, left	41 00 7947385
	Side member rear top right	41 00 7947146		Closing plate, longitudinal member, right	41 00 7947386
	Left shock absorber support	41 00 7947143		Frame side member, rear bottom left	41 00 7947337
	Right shock absorber support	41 00 7947144		Frame side member, rear bottom right	41 00 7947338
	Rear trim panel outer	41 00 7947333		Side member rear top left	41 00 7947147
	Interior tail trim	41 00 8498018		Side member rear top right	41 00 7947148
				Left shock absorber support	41 00 7947143
				Right shock absorber support	41 00 7947144
				Rear trim panel outer	41 00 7947334
				Interior tail trim	41 00 8498020

XM			7 Series & i7		
Series / Chassis	Part name	Part number	Series / Chassis	Part name	Part number
XM / G09	Aluminum		7' / G12	Aluminum	
	Spring strut assembly, front left	41 00 7933485		Frame rail, engine support left	41 00 7359395
	Spring strut assembly, front right	41 00 7933486		Frame rail, engine support right	41 00 7359396
	Front left engine support	41 00 7417571		Spring support left	41 00 7329637
	Front right engine support	41 00 7417572		Spring support right	41 00 7329638
	Wheel housing strut, front left	41 00 7933479		Wheel house front left	41 00 7412925
	Wheel housing strut, front right	41 00 7933480		Wheel house front right	41 00 7412926
	Supporting strut,whl house, exterior rç	41 00 7933507		Wheel house, inner half rear left	41 00 7413087
	Supporting strut,whl house,exterior rç	41 00 7933508		Wheel house, inner half rear right	41 00 7413088
	Supporting strut,whl house,exterior rç	41 00 2464639		Wheel house, inner half rear right (PHEV	41 00 7413082
	Steel			Frame side member, inner left	41 00 7413031
	Rear left engine support	41 00 7933493		Frame side member, inner right	41 00 7413032
	Rear right engine support	41 00 7933494		Covering panel for engine beam left	41 00 7412935
	Reinforcement engine mount rear left	41 00 7933267		Covering panel for engine beam right	41 00 7412936
	Reinforcement engine mount right rear	41 00 7933268		Carrier structure, luggage-comp. floor	41 00 7413072
	Wheel housing strut, front left	41 00 7933479		Carbon fiber	
	Wheel housing strut, front right	41 00 7933480		Reinforcement tube, roof frame, left	41 21 7407057
	Supporting strut, wheel house, exterior	41 00 7933507		Reinforcement tube, roof frame, right	41 21 7407058
	Supporting strut, wheel house, exterior	41 00 7933508		C-pillar reinforcement, left	41 21 7433519
	Supporting strut, wheel house, exterior	41 00 2464639		C-pillar reinforcement, right	41 21 7433520
	Left interior column A	41 00 7933501		Steel	
	Right interior column A	41 00 7933502		Supporting strut,whl house, interior lft	41 00 7412929
	Left engine compartment partition	41 00 7933513		Supporting strut,whl house,interior rght	41 00 7412930
	Right engine compartment partition	41 00 7933514		Carr.supp. w/ VIN, wheel arch fr. right	41 00 2412340
	Crash reinforcement, left	41 00 7933249		Carr.supp. w/o VIN, wheel arch fr. right	41 00 7412954
	Crash reinforcement, right	41 00 7933250		Wheel housing strut, front left	41 00 7412953
	Side frame outer left	41 21 9627439		Rear left engine support	41 00 7412941
	Side frame outer right	41 21 9627440		Rear right engine support	41 00 7412942
	A-pillar with door sill left	41 21 9627447		Connection, side frame, left	41 00 7412943
	A-pillar with door sill right	41 21 9627448		Left engine support reinforcement	41 00 7412951
	Side frame center left	41 21 9627455		Reinforcement, engine support right	41 00 7412952
	Side frame center right	41 21 9627456		Side frame, center left	41 21 9850811
	Reinforcement door sill left	41 21 9627467		Side frame, center right	41 21 9850812
	Reinforcement door sill right	41 21 9627468		Body-side frame left	41 00 7413123
	Reinforcement B-pillar left	41 21 9627463		Body-side frame right	41 00 7413124
	Reinforcement B-pillar right	41 21 9627464		Column A exterior, left	41 00 7413247
	Reinforcement C-pillar lower left	41 21 9627489		Column A exterior, right	41 00 7413248
	Reinforcement C-pillar lower right	41 21 9627490		Body-side frame left	41 00 7413123
	Side frame inner left	41 21 9627451		Body-side frame right	41 00 7413124
	Side frame inner right	41 21 9627452		Column A exterior, left	41 00 7413247
	Support B-pillar upper left	41 00 9627465		Column A exterior, right	41 00 7413248
	Support B-pillar upper right	41 00 9627466		Tension band column C, left	41 21 7413115
	Wheel well rear outer half left	41 21 9627491		Tension band column C, right	41 21 7413116
	Wheel well rear outer half right	41 21 9627492		C-pillar support, left	41 00 7421771
	Reinforcement D-pillar inner left	41 21 9627483		C-pillar support, right	41 00 7421772
	Reinforcement D-pillar inner right	41 21 9627484		Left interior side frame	41 00 7413099
	Left interior column A	41 00 7933261		Right interior side frame	41 00 7413100
	Right interior column A	41 00 7933262		Wheel-house inner panel, rear left	41 21 7421817
	Rear left side member	41 00 7947381		Wheel-house inner panel, rear right	41 21 7421818
	Right rear side member	41 00 7947382		Frame side member, inner left	41 00 7401425
	C-pillar inner left	41 00 9631155		Frame side member, inner right	41 00 7401426
	C-pillar inner right	41 00 9631156		Column B inside right	41 00 7460434
	Wheel well rear inner half left	41 00 9631161		Interior left column B	41 00 7460433
	Wheel well rear inner half right	41 00 9631162		Complete tail trim	41 00 7413094
	Wheel well rear outer half left	41 21 9627491		Outer panel tail trim	41 21 7421812
	Wheel well rear outer half right	41 21 9627492		Series / Chassis	Part name
	End plate, side member, left	41 00 7947385	7' & i7 / G70	Aluminum	
	End plate, side member, right	41 00 7947386		Front left wheelhouse	41 14 5A37961
	Wheel arch extension left	41 12 4A18D51		Wheelhousing, front right	41 14 5A37962
	Wheel arch extension right	41 12 4A18D52		Engine support right	41 00 7359396
	Left shock absorber support	41 00 7947143		Engine support, left	41 00 7359395
	Right shock absorber support	41 00 7947144		Spring support left	41 00 9481881
	Side member, rear lower left	41 00 7947335		Spring support right	41 00 9481882
	Side member, rear lower right	41 00 7947336		Covering panel for engine beam left	41 00 7412935
	Side member rear top left	41 00 7947145		Covering panel for engine beam right	41 00 7412936
	Side member rear top right	41 00 7947146		Side member, inner left	41 11 8844253
	Mount rear seat right	41 00 7947150		Side member, inner right	41 11 8844254
	Mounting for rear seat left	41 00 7947149		Rear left wheelhouse, inner half	41 14 5A37AA1
	Rear trim panel inner	41 00 9631167		Rear right wheelhouse, inner half	41 14 5A37AA2
	Tail cowl outer	41 12 4A18D49		Steel	

i3				
Series / Chassis	Part name	Part number		
i3 / I01	Aluminum		Supporting strut, whl house, interior lf	41 00 7412929
	Front axle module	39 20 6872731	Supporting strut, whl house, interior rg	41 00 7412930
	Wheel house front left	39 20 6867911	Supporting strut, whl house, interior lf	41 14 5A37963
	Wheel house front right	39 20 6867912	Supporting strut, whl house, interior rg	41 14 5A37964
	Side member, front left	39 20 6867909	Rear left engine support (BEV)	41 11 8844231
	Side member, front right	39 20 6867910	Rear right engine support (BEV)	41 11 8844232
	Wheel house strut, front left	41 00 7361763	Rear left engine support	41 11 8844229
	Wheel house strut, front right	41 00 7361764	Rear right engine support	41 11 8844230
	Rear axle module	39 20 6872732	Wheel-house inner panel, rear left	41 14 5A37981
	Carbon fiber		Wheel-house inner panel, rear right	41 14 5A37982
	Body skeleton with chassis number	41 00 2448812	A-column, inner front left	41 14 5A37983
	Body-in-white	41 00 2925493	A-column, inner front right	41 14 5A37984
	Side frame, complete, left	41 00 7451589	Left interior column A	41 14 5A37985
	Side frame, complete, right	41 00 7451590	Right interior column A	41 14 5A37986
	Side frame, exterior, left	41 00 7451585	Cover panel, supporting strut, left	41 14 5A37971
	Side frame, exterior, right	41 00 7451586	Cover panel, supporting strut, right	41 14 5A37972
	Reinforcement, rear window frame top le	41 00 7425619	Bulkhead plate, A-pillar left	41 21 5A37B21
	Reinforcement, rear window frame top ri	42 00 7425620	Bulkhead plate, A-pillar right	41 21 5A37B22
	End piece, rear side frame, outer left	41 00 7359013	Extension, wheel housing strut left	41 14 5A37973
	End piece, rear side frame, outer rig	41 00 7359014	Extension, wheel housing strut right	41 14 5A37974
	End piece, rear side frame, inner left	41 00 7359015	Support, carrier support, left	41 21 5A37B01
	End piece, rear side frame, inner rig	41 00 7359016	Support, carrier support, right	41 21 5A37B02
	Left door sill	41 00 7409379	Splash wall	41 13 5A37950
	Right door sill	41 00 7409380	Cross member, splash wall	41 11 8844228
	Tail trim	41 00 7266943	Supporting strut, front wall	41 11 8844237
	Rear left side member	41 00 7410903	Reinforcement, bulkhead, bottom	41 00 7412972
	Rear right side member	41 00 7410904	Left engine compartment partition	41 00 7412947
	Crossmember, rear upper	41 00 7416300	Right engine compartment partition	41 00 7412948
	Roof cover, without sunroof	51 13 7412389	Mounting, suspension cross-brace, left	41 11 8844235
	Roof cover	51 13 7266944	Mounting, suspension cross-brace, right	41 11 8844236
	Rear window frame	41 00 7451594	Side frame outer left	41 21 5A37B51
			Side frame outer right	41 21 5A37B52
			Column A exterior, left	41 21 5A37B77
			Column A exterior, right	41 21 5A37B78
			Side frame, middle left	41 21 5A37AP5
			Side frame, middle right	41 21 5A37AF6
			Reinforcement shield AT left front side	41 21 5A37B23
			Reinforcement shield AT right front side	41 21 5A37B24
			Crash reinforcement A-pillar left	41 21 5A37B13
			Crash reinforcement A-pillar right	41 21 5A37B14
			Reinforcement side sill left	41 21 5A37B45
			Reinforcement side sill right	41 21 5A37B46
			C-pillar reinforcement, left	41 21 5A37B33
			C-pillar reinforcement, right	41 21 5A37B34
			Tension band column C, left	41 21 5A37B47
			Tension band column C, right	41 21 5A37B48
			Left interior side frame	41 21 5A37AD1
			Right interior side frame	41 21 5A37AD2
			Frame side member, inner left	41 11 8844621
			Frame side member, inner right	41 11 8844622
			Frame side member, inner left (BEV)	41 11 8844633
			Frame side member, inner right (BEV)	41 11 8844634
			Wheel-house inner panel, rear left	41 21 5A37AD3
			Wheel-house inner panel, rear right	41 21 5A37AD5
			Column B inside right	41 21 5A37AF2
			Interior left column B	41 21 5A37AF1
			A-pillar inner rear left	41 21 5A37AE3
			A-pillar inner rear right	41 21 5A37AE4
			Left interior column A	41 14 5A37985
			Right interior column A	41 14 5A37986
			End plate side member rear left	41 11 8844273
			End plate side member rear right	41 11 8844274
			Extension, side member, bottom left	41 11 8844249
			Extension, side member, bottom right	41 11 8844250
			Extension, side member, top left	41 00 7413043
			Extension, side member, top right	41 00 7413044
			Extension, side member, side left	41 11 8844271
			Extension, side member, side right	41 11 8844272
			Extension, side member, bottom left (BEV)	41 11 8844251
			Extension, side member, bottom right (BEV)	41 11 8844252
			Extension, side member, top left (BEV)	41 11 8844257
i8				
Series / Chassis	Part name	Part number		
i8 / I12 I15	Aluminum			
	Front axle module	39 10 8836246		
	Trunk floor	41 00 7370344		
	Tail trim	41 00 7434490		
	Rear end	41 00 7488283		
	Rear axle module	41 10 2973445		
	Front axle module	39 10 8836246		
	Carbon fiber			
	Supporting strut, front wall	41 00 7371982		
	Side frame, complete, left	41 00 7371941		
	Side frame, complete, right	41 00 7371942		
	Side frame, exterior, left	41 00 7371937		
	Side frame, exterior, right	41 00 7371938		
	Cover, rocker panel, left	41 00 7323563		
	Cover, rocker panel, right	41 00 7323564		
	Side frame, complete, left	41 00 7371941		
	Side frame, complete, right	41 00 7371942		
	Left interior side frame	41 00 7371933		
	Right interior side frame	41 00 7371934		
	C-pillar reinforcement, left	41 00 7305935		
	C-pillar reinforcement, right	41 00 7305936		
	Rear window frame	41 00 7371980		
	Connector, rear window frame, top rig	41 00 7305948		
	Connector, rear window frame, upper le	41 00 7305947		
	Left side member	41 00 9631613		
	Right side member	41 00 9631614		
	Reinforcement for side member, left	41 00 7305683		
	Reinforcement for side member, right	41 00 7305684		
	Roof	51 13 7305915		
	Upper apron	41 00 7371981		
	Connector, windshield cowl, lateral, le	41 00 7305941		
	Connector, windshield cowl, lateral, ri	41 00 7305942		
	Connector, rear window frame, top rig	41 00 7305948		
	Connector, rear window frame, upper le	41 00 7305947		
	Door front left	41 51 7312667		
	Door front right	41 51 7312668		

8 Series & M8		
Series / Chassis	Part name	Part number
8' & M8 / F9x G1x	Aluminum	
	Frame rail, engine support front left	41 00 7359395
	Frame rail, engine support front right	41 00 7359396
	Spring support left	41 00 7329873
	Spring support right	41 00 7329874
	Rear left wheelhouse	41 00 7499111
	Rear right wheelhouse	41 00 7499112
	Rear left wheelhouse	41 00 7499115
	Rear right wheelhouse	41 00 7499116
	Wheel house front left	41 00 7446651
	Wheel arch w/o VIN front right	41 00 7446652
	Wheel arch w/ VIN front right	41 00 2456303
	Wheel arch, carry support w/ VIN front	41 00 2433159
	Wheel arch, carry support w/o VIN front	41 00 7446654
	Rear side member left	41 00 7381815
	Rear side member right	41 00 7381816
	Rear side member left	41 00 7443883
	Rear side member right	41 00 7443884
	Wheel house rear left	41 00 7499111
	Wheel house rear right	41 00 7499112
	Wheel house rear left	41 00 7499115
	Wheel house rear right	41 00 7499116
	Wheel house rear left	41 00 7428899
	Wheel house rear right	41 00 7428900
	Body base frame rear	41 00 7499120
	Body base frame rear	42 00 7499121
	Body base frame rear	41 00 7499122
	Steel	
	Carr.supp. w/ VIN, wheel arch fr. rig	41 00 2433159
	Carr.supp. w/o VIN, wheel arch fr. rig	41 00 7446654
	Supporting strut,whl house, interior	41 00 7446653
	Wheel housing strut, front left	41 00 7446669
	Wheel housing strut, front right	41 00 7446670
	Rear left engine support	41 00 7412941
	Rear right engine support	41 00 7412942
	Connection, side frame, left	41 00 7412943
	Rear right engine support	41 00 7412942
	Left engine support reinforcement	41 00 7412951
	Reinforcement, engine support right	41 00 7412952
	Wheel-house inner panel, rear left	41 00 7412963
	Wheel-house inner panel, rear right	41 00 7412964
	A-column, inner front left	41 00 7446657
	A-column, inner front right	41 00 7446658
	Left interior column A	41 00 7496829
	Right interior column A	41 00 7496830
	Extension, wheel housing strut left	41 00 7446667
	Extension, wheel housing strut right	41 00 7446668
	Left engine compartment partition	41 00 7412947
	Right engine compartment partition	41 00 7412948
	Extension, side member, top right (BEV)	41 11 8844258
	Extension, side member, side left (BEV)	41 11 8844271
	Extension, side member, side right (BEV)	41 11 8844272
	Mount, bumper left	41 00 9630049
	Mount, bumper right	41 00 9630050
	Complete tail trim	41 13 5A37AA8
	Outer panel tail trim	41 34 5A37AA9
	iX	
Series / Chassis	Part name	Part number
iX / I20	Aluminum	
	Body carcass with panorama roof	41 00 9633236
	Engine support right without VIN	41 00 9880896
	Engine support left	41 00 9880895
	Engine support with VIN	41 00 9633342
	Strut tower, front left	41 00 9880899
	Strut tower, front right	41 00 9880900
	Support strut tower top left	41 00 9880903
	Support strut tower top right	41 00 9880904
	Repair adapter strut tower front left	41 00 9880901
	Repair adapter strut tower front right	41 00 9880902
	Repair adapter strut tower rear left	41 00 9623781
	Repair adapter strut tower rear right	41 00 9623782
	Holder, brake hose, front left	41 00 9880905
	Holder, brake hose, front right	41 00 9880906
	Repair panel carrier support bottom	41 00 9623787
	Repair panel carrier support top outer	41 00 9624947
	Repair panel carrier support top inner	41 00 9624948
	Repair element engine support	41 00 9623785
	Repair panel engine support	41 00 9627391
	Repair element carrier support	41 00 9623786
	Repair element side member	41 00 9626980
	End plate side member front	41 00 9629449
	Repair panel end plate side member left	41 00 9629451
	Repair panel end plate side member right	41 00 9629452
	Repair panel side member	41 00 9626981
	End plate side member rear	41 00 9629448
	Side member, rear	41 00 9880909
	Repair panel side member	41 00 9626979
	Trunk floor	41 00 9629397
	Luggage compartment pan	41 00 9629381
	Roof panel	41 00 9630944
	Side member, rear	41 00 9880909
	Carbon fiber	
	Left water channel cover	41 00 9883243
	Right water channel cover	41 00 9883244
	Reinforcement, interior roof frame, left	41 00 9465767
	Reinforcement, interior roof frame, right	41 00 9465768
	Upper apron	41 00 9630957
	Rear Window frame	41 00 9630951
	Side frame, exterior, left	41 00 9447285
	Side frame, exterior, right	41 00 9447286

Side frame, middle left	41 00 7494263
Side frame, middle right	41 00 7494264
Reinforcement, interior roof frame, left	41 00 7494271
Reinforcement, interior roof frame, right	41 00 7494272
Reinforcement column C, bottom, left	41 00 7494273
Reinforcement column C, bottom, right	41 00 7494274
Left interior side frame	41 00 7494265
Right interior side frame	41 00 7494266
Wheel arch outer rear left	41 00 7494259
Wheel arch outer rear right	41 00 7494260
Frame side member, inner left	41 00 7480955
Frame side member, inner right	41 00 7480956
Body base frame rear	41 00 7499122
Closing plate, longitudinal member, left	41 00 7499097
Closing plate, longitudinal member, right	41 00 7499098
Luggage compartment pan	41 00 7431362
Extension, side member, top left	41 00 7499089
Extension, side member, top right	41 00 7499090
Left side member extension	41 00 7499083
Right side member extension	41 00 7499084
Reinforcement side member bottom left	41 00 7499085
Reinforcement, side member, bottom right	41 00 7499086
Complete tail trim	41 00 7494451
Rear trim panel outer	41 00 7494414
Side frame, middle left	41 00 7494431
Side frame, middle right	41 00 7494432
Reinforcement, interior roof frame, left	41 00 7494447
Reinforcement, interior roof frame, right	41 00 7494448
Left upper column B reinforcement	41 00 7465731
Right upper column B reinforcement	41 00 7465732
Left interior side frame	41 00 7494419
Right interior side frame	41 00 7494420
Wheel arch outer rear left	41 00 7494423
Wheel arch outer rear right	41 00 7494424
End plate, wheel arch, outer, left	41 00 7494427
End plate, wheel arch, outer, right	41 00 7494428
Frame side member, inner left	41 00 7480953
Frame side member, inner right	41 00 7480954
Connection, side frame, left	41 00 7412943
Rear right engine support	41 00 7412942
Body base frame rear	41 00 7499121
Closing plate, longitudinal member, left	41 00 7499095
Closing plate, longitudinal member, right	41 00 7499096
Extension, side member, top left	41 00 7499087
Extension, side member, top right	41 00 7499088
Left side member extension	41 00 7499081
Right side member extension	41 00 7499082
Frame side member, inner left	41 00 7480951
Frame side member, inner right	41 00 7480952
Body base frame rear	41 00 7499120
Luggage-compartment floor, rear	41 00 7499124
Side frame, middle left	41 00 7494517
Side frame, middle right	41 00 7494518
Column A exterior, left	41 00 7494519
Column A exterior, right	41 00 7494520
Left interior side frame	41 00 7494531
Right interior side frame	41 00 7494532
Complete tail trim	41 00 7494451
Rear trim panel outer	41 00 7494414
Reinforcement B-pillar left	41 00 7494515
Reinforcement B-pillar right	41 00 7494516
Wheel arch outer rear left	41 00 7494533
Wheel arch outer rear right	41 00 7494534

Steel	
Side frame, middle left	41 00 9630961
Side frame, middle right	41 00 9630962
Left outer roof frame panel	41 00 9630973
Right outer roof frame panel	41 00 9630974
A-pillar, bottom left	41 00 9630965
A-pillar, bottom right	41 00 9630966
B-pillar centre left	41 00 9630967
B-pillar centre right	41 00 9630968
Reinforcement column C, bottom, left	41 00 9630985
Reinforcement column C, bottom, right	41 00 9630986
Reinforcement for D-pillar bottom left	41 00 9630977
Reinforcement for D-pillar bottom right	41 00 9630978
Repair element, side member	41 00 9626980
U-beam with nuts side member	41 00 9631363
Left interior side frame	41 00 9630949
Right interior side frame	41 00 9630950
Wheelhouse rear, outer half left	41 00 9630953
Wheelhousing, rear, outer section, right	41 00 9630954
Column B inside right	41 00 9630970
Interior left column B	41 00 9630969
B-pillar inner bottom left	41 00 9629455
B-pillar inner bottom right	41 00 9629456
End plate, wheel arch, outer, left	41 00 9629453
End plate, wheel arch, outer, right	41 00 9629454
Connection B-pillar trim panel left	41 00 9630979
Connection B-pillar trim panel right	41 00 9630980
Reinforcement column B inside left	41 00 9630975
Reinforcement column B inside right	41 00 9630976
Rear left wheelhouse, inner half	41 00 9629387
Rear right wheelhouse, inner half	41 00 9629388
Luggage compartment floor side left	41 00 9629375
Luggage compartment floor side right	41 00 9629376
Reinforcement wheel arch front left	41 00 9629393
Reinforcement wheel arch front right	41 00 9629394
Reinforcement wheel arch rear left	41 00 9629395
Reinforcement wheel arch rear right	41 00 9629396
Support belt reel, left	41 00 9629391
Support belt reel, right	41 00 9629392
Extension for rear left wheel well	41 00 9629385
Extension for rear right wheel well	41 00 9629386
Complete tail trim	41 00 9629398
Outer panel tail trim	41 00 9629399